


A tip from Daniel Northern of our 191 Shop:

JH H / GH J (r) having no start calls or always having dead batteries on the lot? Check the ignition switch to see if the key can be removed in any position other than "LOCK".



Incorrect



Key has been removed
in the accessory
position. Radio and
a/c controls are still on
resulting in dead
battery.



Incorrect

The key has
been
removed
while the
truck is
running.

Incorrect



The radio is staying on and draining the battery because the key has been removed while the ignition switch is in the "accessory" position.