

## A/C COMPRESSOR SERPENTINE BELT BYPASS—ALL 2005–08 JH-K/M/A/B U-HAUL® TRUCKS

Follow the procedure outlined in these instructions to bypass the A/C system when a compressor has locked up. A shorter serpentine belt is used to temporarily replace the original belt so that instead of being towed, an inoperable truck can be driven to a repair facility. The following instructions are for **EMERGENCY ROADSIDE REPAIRS ONLY**. Once the procedure is complete, drive the truck to the nearest repair facility for a full A/C system diagnostics.

### Procedure



Figure 1




Figure 2

**IMPORTANT NOTE:** The following instructions are for **EMERGENCY ROADSIDE REPAIRS ONLY**. Once the procedure is complete, drive the truck to the nearest repair facility for full A/C system diagnostics.

1. Remove the air cleaner assembly (Figure 1).
2. Remove the existing serpentine belt (Figure 2). Discard if damaged.




Figure 3



Figure 4


3. Remove the idler pulley and set aside (Figure 3).
4. Remove the top alternator bolt and set aside (Figure 4).



The information in this technical bulletin is intended for use by trained, professional technicians with the knowledge, tools and equipment to do the job properly and safely. Remember: Always wear proper personal protective equipment (PPE).

5. Install the bypass serpentine belt (product number 885K6). Refer to **Figure 5** for routing instructions.  
**NOTE:** It is not necessary to remove the A/C compressor.
6. Reinstall the air cleaner assembly.
7. Place the alternator bolt and idler pulley in the center console or secure beneath the passenger's-side seat for later reinstallation.

**Claim Labor Operation 2102.**



**Figure 5**

**Repair Reporting**

Operation No.	Qty	Hours	Description	Cause
2102	EA	.04	JH-K/M/A/B A/C Bypass Procedure	N

Enter your questions and comments via the EPI Feedback or contact Ray Bishop, at 1-800-223-6218, VoIP 460224 or Ray\_bishop@uhaul.com.